

Instructions



Introduction

Cloudtap's Scaleclear water conditioners protect your pipes, appliances, and glass/tapware from limescale and hard water damage without stripping healthy minerals or increasing sodium levels in your drinking water.

Important



- Scaleclear products should only be installed by a licensed plumber.
- Make sure you have selected the correct Scaleclear model for your home's flow rate (check the table on the back of the box).
- Turn off your mains supply and drain any relevant pipes before installation.



How to install

1. Locate and measure out the section of pipe that will be removed for the Scaleclear unit.
2. After removing the section of pipe and noting the indicated flow direction, fit the Scaleclear unit (3/4" BSP male inlet and outlet).
3. **Slowly** turn the water supply back on, checking for leaks as pressure is restored.

And that's it! Congratulations, your Scaleclear conditioner is fully installed.

This product is in compliance with the lead free requirements of the clause A5G4 of National Construction Code (NCC) 2022 Volume Three – Plumbing Code of Australia.

No service required

The following claims have not been independently verified.

Warning – For correct operation of this system it is essential to observe the manufacturers instructions.

Caution – Do not use with water that is micro biologically unsafe or with water of unknown quality without adequate disinfection before or after the system.

Pressure range:	Temperature range:	Flow rates:	Certificate no:
1–1600 kPa	0–20 °C (for potable water systems)	CT-SCLF: 3–25 l/min CT-SCHF: 24–54 l/min	WM23531 AS3497

For support or information regarding installations, maintenance, and operation of Scaleclear and other Cloudtap products, call 08 9202 6909 or email info@cloudtap.com.au.